
## **LMI INSTALLATION**



The new LMI systems will monitor crane configurations such as outrigger deployed, operating in high gantry or pile driving. They will also keep track of boom angle, load, rotation and superelevation.

The system is pre-programmed with the specific load charts for the crane it is to be installed on and provides an audible alarm when the operator is approaching the limitations built into those charts.

IPS can install a new LMI system on cranes that have never had them, or replace outdated systems.